EcoOnline™ 12V/24V Solar Regulator

For the EcoOnline Solar Kits using the

1R/20Amp/24V

Solar Charge Controller

Installation Manual & User Manual - Revised 23/05/2017



Optex Solar Pty. Ltd. ABN: 88 128 228 884 www.EcoOnline.com.au email: <u>info@EcoOnline.com.au</u>

© Copyright 2012 Optex Solar Pty Ltd. All rights strictly reserved. This publication is protected by copyright law and unless otherwise specified is for your personal and non-commercial use only. No part of this publication may be reproduced or distributed by any process, electronic or otherwise, without the specific written permission of Optex Solar Pty Ltd. Trademarks appearing in this manual are the sole property of Optex Solar Pty Ltd or their respective owners. Nothing in this publication shall be construed as granting any express or implied license to use any intellectual property of Optex Solar Pty Ltd otherwise than for personal and non-commercial use only. Optex Solar Pty Ltd must not, to the full extent permitted by law, be held liable for any claim, cost (including legal costs), damage, expense, loss (including fines, penalties, set-offs and consequential loss) or liability arising from the use (or misuse) of any product described in this publication, unless expressly provided otherwise in this publication. Information as well as any products described in this publication are subject to change without notice.

EcoOnline[™] Solar Regulator Kit -- Installation and User Manual © Copyright 2012 Optex Solar Pty Ltd. All rights strictly reserved.





Contents

1	Key Terms	3
2	Safety Requirements	4
3	Warranties	5
4	Included Kit Components (depending on the kit purchased)	5
5	Designing Your Charging System	6
6	Connecting the Load Direct to Battery or Through the Regulator	6
7	Recommend Position of Regulator	7
8	Fuse and Technical Wiring Diagrams	8
9	Fuse Assembly	8
10	Solar Panel Wiring	11
11	Wiring in Twin Folding Panels	14
12	Connecting the MC4 Connector	15
13	Mounting the Solar Panel(s)	16
14	Mounting the Charging Regulator	17
15	Regulator Connections	17
16	Wiring and Connection Order	18
17	Auto Voltage Selection - 12V or 24V System	18
18	Lap Splice Soldered Connection	19
19	Connector Dismantling Procedure (if required)	20
20	System Grounding	21
21	Specifications	23
22	Operating Instructions	24
23	System Maintenance	25
24	Trouble Shooting Guide	25

1 Key Terms

Congratulations on the purchase of your EcoOnline[™] Solar Regulator Kit. Please print this manual out for your reference. Please take the time to read the manual before starting any work. Particular attention should be given to text contained in the following key terms.

Please note EcoOnline has a strong product safety policy; do not install products without reading safety guidelines in the manual. Please report any product safety issues or near misses to info@EcoOnline.com.au no matter how trivial.



2 Safety Requirements





3 Warranties

EcoOnline[™] offers the following Warranties

• 3 year limited Warranty on all Regulators

See EcoOnline.com.au <u>Terms and Conditions</u> page for further details.

4 Included Kit Components (depending on the kit purchased)

			T HIC 1214 DHK HA
20Amp Solar Charging Regulator	two core 1.0mm ² -1.5mm ²	single core 2.5 -4mm ²	20Amp Fuse holder,
	5m Solar Wire (10Amp)	Battery Wire	30Amp fuse kit.

5 Designing Your Charging System

Firstly, please visit our online sizing calculators to size your system. They will help you understand important factors involved in sizing a solar charging regulator system. (Do not assume the supplied components are suitable for all situations!)

- 1. <u>Solar Panel Sizing Calculator</u> (this will help you understand the factors involved in a sizing solar panels)
- 2. <u>Solar Regulator Calculator</u> (this will help you understand the factors involved sizing a regulator)
- 3. <u>Solar Wire Sizing Calculator</u> (this will help you understand the factors involved in sizing wire gauges)



A charging system must be sized right, for efficiency, reliability and **safety**. If in doubt please seek advice.

6 Connecting the Load Direct to Battery or Through the Regulator

The first choice you have to make is whether you will be connecting your 12V/24V load direct to the battery or through your regulator.



Solar Charging Setup Options

Option 1: (Recommended) Advantages	Option 2: Advantages
* Regulator will protect the battery from low voltage	* Regulator and regulator to battery wire need only be
deep discharge	sized to the maximum power of the solar panels
Option 1: Disadvantages	Option 2: Disadvantages
Option 1: Disadvantages * Expensive high gauge wire will be needed if you have a	Option 2: Disadvantages * No deep cycle protection for the battery
Option 1: Disadvantages * Expensive high gauge wire will be needed if you have a high power load and a long battery to regulator distance	Option 2: Disadvantages * No deep cycle protection for the battery

We recommend the regulator be positioned near the battery.





9 Fuse Assembly

Step 1: Choose a conveniently accessible, rain sheltered location for the fuse assembly.



Note: the fuse assembly should be close to the battery but no closer than 150mm from the battery terminals.



For the battery to regulator wire, if you are also connecting the load through the regulator you need to consider max load current not just the max charging current. You may need a substantially higher gauge wire.



Step 2: Measure and cut the **battery to regulator** cables. For the +ve positive line cut the wire at the chosen fuse holder location. Strip and tin solder all wires appropriately in preparation for a lap splice, follow Section 18 below.

NOTE: Before you solder **don't forget to thread all** FOUR heat shrink tubes.

Step 3: Solder the fuse holder in-line at both ends using a lap splice. Tape down ends to hold in place during soldering. **Clean flux residue from the solder using suitable solvent.**

Step 4: Use a heat gun to the heat shrink the first sleave. You'll need a glove to protect your fingers when you press the hot heat shrink firmly around the wire so that the hot adhesive creates a good seal.



Step 5: Use a heat gun to the heat shrink the second sleave. The fuse assembly is complete and ready for mounting.



Note: Fuse assembly is only dust proof and should not be exposed to the sun and moisture. Fuse assembly and wire should be fixed in place to prevent wire movement and fatigue. There should be no flammable objects in contact with or above and below the fuse assembly. If the solder or fuse connections become corroded, or fatigued over time, resistive heating in these connections can result in a fire. Depending on the installation the entire fuse assembly should be placed in an electrical junction box.

10.1 Solar Connection Using Twin Core Wire and Connector – for 12V system



10.2 Solar Connection Using Single Core Wire and MC4 Connectors – for 12V system





NEVER screw clamp solder tinned wires to the solar junction box terminals. Wires must be soldered onto the terminals inside the junction box.



Always check that the solar modules are wired for the same voltage as the battery by using a **multimeter**. Open circuit voltage of a "12V nominal" or 36 cell solar panel or in parallel connected solar panels should be around 21V. This should be doubled for a 24V system.

10.3 In Parallel Connection Using Twin Core Wire – for 12V system



10.4 In Parallel Connection Using Single Core Wire – for 12V system



10.5 In Series Connection Using Twin Core Wire - for 24V system



10.6 In Series Connection Using Single Core Wire – for 24V system







Always check that the entire solar array is wired for the same voltage as the battery by using a **multimeter**. Open circuit voltage of a "12V nominal" or 36 cell solar panel or in parallel connected solar panels should be around 21V. This should be doubled for a 24V system.



Read Carefully

CAUTION

Panels wired in series must be of equal power and face exactly the same direction. Panels wired in parallel can face different directions. Your solar panel may have come with wire and MC4 connectors on the ends. You will need to source compatible opposing MC4 connector plugs to make connections to the solar panels MC4 connectors (if not purchased).





Note: the **male metal pin is used in the female plastic MC4** connector and vice verse for the female metal pin.

The MC4 connector metal pin must be crimped onto the solar wire using appropriate Australian Standard crimping tools. We recommend you also solder the crimped connection for better electrical contact, but only after a secure and tight crimp is performed.

WARNING

13 Mounting the Solar Panel(s)

13.1 Mounting on Building Roof or Caravan



If the panels are to be mounted on a building roof **always check council/building regulations in your area**. We recommend roof mounting of panels be performed by a qualified professional that can advise on appropriate mounting means for your situation.

Generally, when mounting panel we also recommend:

- Panel(s) should be mounted as close to the ground as possible for ease of maintenance, reduced wind loading, shorter wire runs and a reduced chance of lighting strike
- Electrical connections in junction box **MUST be soldered on**.
- The underside moisture barrier should not be scratched as this the will severely limit panel lifetime.
- **Do not use self taping screws** into the side of frame when installing panels; use the bolt holes on the back with locking bolt & nut set or commercially available mounting means.
- Panels should be installed with 20mm to 50mm underside ventilation gap.

13.2 Portable/Folding Solar Camping Panel(s)



We recommend portable/folding panels are placed on a secure, flat, **non-flammable surface** exposed to the sun. As a precaution **do not place panels on or in dry flammable grass for example**.



For portable/folding panels with a regulator on the back we also recommend you discontinue use if the outside temperature is greater than 40DegC. Note: the regulator and fuse holder must have air flow during use; do not cover system components.



We recommend the portable/folding panels be put away in very strong wind, or if there is a chance of lighting. In moderate winds a heavy object can be place on the frame legs to secure again overturning.





The controller must be mounted on a **vertical**, **non-flammable surface**, in a cool, dry, sheltered location with adequate ventilation. **Note: the heat sink will get hot under operation.** Ensure that there is sufficient air flow around the back of the controller.

15 Regulator Connections





16 Wiring and Connection Order





17 Auto Voltage Selection - 12V or 24V System



Note: the controller will sense and set the system voltage from the battery voltage. If the battery voltage is lower than 18V, it will recognize the system as 12V. If the battery voltage is greater than 18V, it will recognize the system as 24V.

18 Lap Splice Soldered Connection



A soldered lap splice can be used with this kit to make connection but **ONLY for applications** where the wiring and splice joins are to be fixed in place WITHOUT potential for tension or repetitive bending movement across splice joins. Use ONLY rosin-core solder that is specifically approved for electrical work.





Overlap area should be **at least 3 wire diameters but no more than 5 diameters**. Wire overlap must be well pre-tinned with solder.

* DO NOT nick wire while stripping insulation
* DO NOT allow solder to diffuse into the length of the wire more than 5 wire diameters from tip.

Solder the overlapping wire ends **together across the entire overlap** using sufficient heat to fully melt the solder. Tape down ends to hold in place during soldering. Clean flux residue from the solder using suitable solvent. Cut off any protruding wire strands.

* DO NOT allow movement during the solder solidification process



* DO NOT use a naked flame or soldering iron to shrink heat shrink sleave



Apply secondary heat shrink sleave to immobilize the splice to protect against metal fatigue of solder. Press ends to seal.

* DO NOT expose the stiff splice to tension or metal fatiguing bending forces. When mounting soldered splice should be fixed in place at both ends.





Note: you may need to compress the *main body* of the connector to break the glue seal. This should be performed by gently compressing the *main body* until you hear the seal break.



Note the 10Amp limit for these connectors. We recommend connectors are not mounted such that they are continuously exposed to rain and water ingress.

20 System Grounding

Grounding the regulator is not technically required for simple camping type stand-alone solar systems.



If for some reason grounding is required it should be noted that this is a **positively ground regulator**. (See below for allowed grounding configurations.)





Grounding option 2 and 3 should be used with **caution** as for these configurations the controllers positive wires cannot be allowed make electrical contact to the ground or the car frame.



When using Option 3, never mount the regulator near grounded chassis parts and always secure the wires going into the regulator as they could become loose and potentially fall out touching chassis parts.

20.1 Frame Grounding Option



20.2 Forbidden Grounding Options



21.1 General Regulator Specifications

General Specifications		
Description Parameter		ter
Nominal System Voltage 12VDC 24VD		24VDC
Battery Voltage Range	9V-16V	18V-32V
Recommended Solar Panel	36 cell	72 cell
Maximum Short Term Current	20A	
Maximum Continuous Current	15A	
Charge Circuit Voltage Drop	≤0.26V	
Discharge Circuit Voltage Drop	≤0.15V	
Self-consumption	≤6mA	
Temperature Compensation Coefficient*	-30mV/°C/12V (at 25°C)	
Terminal size	6mm	
Operating temperature	-10°Cto +45°C	
Storage temperature	-35°C to +70°C	
Humidity	Max. 90%	
Enclosure IP30		
Regulator Physical Dimensions length 144mm x width 75.8mm		8mm x height 45mm

* Compensates equalize, boost, float and low voltage disconnect voltages.

Lead Acid Battery Types			
Regulator selection GEL		SEALED	FLOODED
Common names	"VRSLAB" also "Sealed" or "Maintenance free"		Lead Acid Battery*
Technical name	Gelled Electrolyte	Advanced Glass Mat (AGM)	Wet Cell Lead Acid
Electrolyte type Gel suspension		Glass mat suspended liquid	Liquid

* Note some wet cell batteries have sealed tops and are marketed as "maintenance free" however these are still classed as FLOODED type batteries.

Battery Voltage Charging Parameters (at 25°C)			
Charging	GEL	SEALED	FLOODED
Parameter	12V(24V)	12V(24V)	12V(24V)
Equalize Charging Voltage		14.6V (29.2V)	14.8V (29.6V)
Boost Charging Voltage	14.2V (28.4V)	14.4V (28.8V)	14.6V (29.2V)
Float Charging Voltage	13.8V (27.6V)	13.8V (27.6V)	13.8V (27.6V)
Boost Reconnect Charging Voltage	13.2V (26.4V)	13.2V (26.4V)	13.2V (26.4V)
Low Voltage Reconnect Voltage	12.6V (25.2V)	12.6V (25.2V)	12.6V (25.2V)
Under Voltage Warning Reconnect Voltage	12.2V (24.4V)	12.2V (24.4V)	12.2V (24.4V)
Under Voltage Warning Voltage	12.0V (24.0V)	12.0V (24.0V)	12.0V (24.0V)
Low Voltage Disconnect Voltage	11.1V (22.2V)	11.1V (22.2V)	11.1V (22.2V)
Discharging Limit Voltage	10.8V (21.6V)	10.8V (21.6V)	10.8V (21.6V)
Equalize Duration		2 hours	2 hours
Boost Duration	2 hours	2 hours	2 hours



Indicating Light(s)	System Status	
RED Sealed, Gel OR Flooded light ON Solid	Indicates the charging profile selected	
RED Sealed, Gel, Flooded lights flashing simultaneously	indicates the controller is overheated	

To select the battery type SEALED, GEL or FLOODED (and hence appropriate charging profile):

- Hold down Control Button for 8 second until Battery Type Selection light starts flashing
- Press Control Button again to toggle through battery type selection
- Hold down **Control Button** again for 8 second to save selection until the appropriate **Battery Type Selection** light remains ON solid.

4 - Load Active Light		
Indicating	Charging Status	
RED light OFF Solid	Load OFF (Not Active)	
RED light ON Solid	Load ON or Active	

RED light Flashing	Overload or Short
--------------------	-------------------

23 System Maintenance



Important: before carrying out any system maintenance you MUST check for any manual updates and download the latest installation manual from www.EcoOnline.com.au/downloads

The following inspections and maintenance tasks are recommended at least two times per year for best controller performance.

- Check that the controller is securely mounted in a clean and dry environment.
- Check that the air flow and ventilation around the controller is not blocked. Clear all dirt or fragments on the heat sink.
- Check fixings holding wiring in place.
- Check all wires to make sure insulation is not damaged from, UV exposure, frictional wear, moisture/corrosion, fatigue, insects or rats etc. Maintain or replace the wires if necessary.
- Make sure all terminal connections are tight. Inspect regulator connections for loose, corroded, broken, wires or signs of high temperatures such as discoloured or burnt areas.
- Confirm that all the system components are ground connected tightly and correctly if the system is grounded.
- Check that any fuses and fuse holders are not corroded and/or lose and/or warm or hot during operation. Replace as needed.



Fatigued, weathered, loose and/or corroded wiring or electrical connections poses a fire risk even at low voltage. The systems wiring should be checked periodically for any wear, cracking resulting from UV damage of insulation on wiring and corrosion of any solder or controller connections. Any affected parts should be replaced at the first sign of damage.

24 Trouble Shooting Guide

Firstly, connect battery to regulators battery terminals (Note: battery <u>MUST</u> be at least 6V) **Does the regulator battery light turn ON?** (Note: battery light is typically very faint)

